CMCcare Thumb Brace

Sizing Instructions



For the best fit and function you only need one measurement

Measure the length from your web space to your wrist crease

S	2” - 2 1/2” (5.1 - 6.4cm)
M	2 1/2” - 3” (6.4 - 7.6cm)
L	3” - 3 1/2” (7.6 - 8.9cm)

Sizing Tips:

If the measurement is near the end of a range, consider the following when choosing size:

- Choose the smaller size if hands are thin and the thumb muscles are soft or flattened
- Choose the larger size if hands are fuller and the thumb muscles are large and firm

It may be necessary to try two sizes on your patient for the best fit