Cubicle Curtain Factory Inc.

McK66 SnapToCurtain®

How to Measure

Panels Required per Track

(1). REQUIRED HORIZONTAL WIDTH:

a. Measure full width of existing ceiling track (or) new track layout

b. Divided by sixty (60) = ____ Number of panels required

(Round up quantity to next full panel)

(2). REQUIRED VERTICAL LENGTH:

a. Measure from ceiling to floor (tight) in inches

b. Subtract twelve inches (-12") = ____ finished length

(Includes (+/-) 20" antimicrobial top mesh – required by NFPA701 fire code)

Industry standard finished vertical lengths:
84" / for eight-foot (8') ceiling to floor
96" / for nine-foot (9') ceiling to floor
108" / for ten-foot (10') ceiling to floor

FOR CEILING TO FLOOR GREATER THAN 10' OR EXISTING SUSPENDED TRACK,
CALL 800-588-9296

Call with questions or help with measuring: (800) 588-9296

All products manufactured in USA / 180-day warranty on labor and materials

Proprietary measuring and manufacturing system / Registered Trademark US Patent Office